

# **GEOPAK Drainage V8i Course Manual**



**Tennessee Department of Transportation  
Roadway Design Division**

## Trademarks

GEOPAK & MicroStation are registered trademarks of Bentley Systems, Incorporated.

Other brands and product names are the trademarks of their respective owners.

The information in this manual is based on the following software versions:

MicroStation V8i - SELECT Series 2 Edition (08.11.07.443)

GEOPAK V8i – SELECT Series 2 Edition (08.11.07.615).

## Resources

Tennessee Department of Transportation Drainage Manual:

[http://www.tdot.state.tn.us/Chief\\_Engineer/assistant\\_engineer\\_design/design/DrainManChap%201-11.htm](http://www.tdot.state.tn.us/Chief_Engineer/assistant_engineer_design/design/DrainManChap%201-11.htm)

Tennessee Department of Transportation Design Guidelines and Instructional Bulletins:

[http://www.tdot.state.tn.us/Chief\\_Engineer/assistant\\_engineer\\_design/design/DesGuide.htm](http://www.tdot.state.tn.us/Chief_Engineer/assistant_engineer_design/design/DesGuide.htm)

Tennessee Department of Transportation Design V8 CADD Standards and Downloads:

[http://www.tdot.state.tn.us/Chief\\_Engineer/assistant\\_engineer\\_design/design/v8/V8design.htm](http://www.tdot.state.tn.us/Chief_Engineer/assistant_engineer_design/design/v8/V8design.htm)

Tennessee Department of Transportation Standard Drawings Library:

[http://www.tdot.state.tn.us/Chief\\_Engineer/engr\\_library/stdlib.htm](http://www.tdot.state.tn.us/Chief_Engineer/engr_library/stdlib.htm)

Federal Highway Administration Hydraulic Engineering Circular NO. 22, Second Edition  
Urban Drainage Design Manual:

<http://isddc.dot.gov/OLPFiles/FHWA/010593.pdf>

# GEOPAK Drainage V8*i*

## Course Manual

### Table of Contents

- 1 Getting Started**
  - 1.1 Project Workflow
  - 1.2 Drainage Components
  - 1.3 Directory Information
  - 1.4 GEOPAK User Preferences
  - 1.5 GEOPAK Drainage Menu
  - 1.6 Project Preferences
  - 1.7 Drainage Library
- 2 Land Use DGN Files**
  - 2.1 Land Use DGN Creation
- 3 DTM Drainage Tools**
  - 3.1 Accessing DTM Drainage Tools
  - 3.2 Delineate Watershed
  - 3.3 Drainage Patterns
  - 3.4 Downstream Trace
  - 3.5 Flow Arrows
  - 3.6 Delineate Low Points
  - 3.7 Ridge Lines
  - 3.8 Surface Ponds
  - 3.9 Pond Analysis
- 4 Culverts**
  - 4.1 Delineate the Drainage Area
  - 4.2 Design the Culvert
  - 4.3 Culvert Profile
- 5 Storm Drainage Nodes**
  - 5.1 Design Drainage Node CB-1
  - 5.2 Delineate Drainage Area CB-1
  - 5.3 Design Inlet CB-2
  - 5.4 Delineate Drainage Area CB-2
  - 5.5 Design Inlet CB-3
  - 5.6 Delineate Drainage Area CB-3
  - 5.7 Design Inlet CB-4
  - 5.8 Delineate Drainage Area CB-4
  - 5.9 Design Inlet CB-5
  - 5.10 Delineate Drainage Area CB-5

- 5.11 Design Inlet CB-6
- 5.12 Delineate Drainage Area CB-6
- 5.13 Design Inlet CB-7
- 5.14 Delineate Drainage Area CB-7
- 5.15 Design Inlet CB-8
- 5.16 Delineate Drainage Area CB-8
- 5.17 Design Inlet CB-9
- 5.18 Delineate Drainage Area CB-9
- 5.19 Design Inlet CB-10
- 5.20 Delineate Drainage Area CB-10
- 5.21 Design Inlet CB-11
- 5.22 Delineate Drainage Area CB-11
- 5.23 Design Inlet CB-12
- 5.24 Delineate Drainage Area CB-12
- 5.25 Design Inlet CB-13
- 5.26 Delineate Drainage Area CB-13
- 5.27 Design Inlet CB-14
- 5.28 Delineate Drainage Area CB-14
- 5.29 Design Junction MH-1
- 5.30 Design Outlet EW-1
- 5.31 Inlet Bypass

## **6 Storm Drainage Links and Network**

- 6.1 Link Design
- 6.2 Curved Links
- 6.3 Storm Drainage Network Design

## **7 Ditch Nodes and Links**

- 7.1 Ditch Node Design DIT-1
- 7.2 Delineate Drainage Area DIT-1
- 7.3 Ditch Node Design DIT-2
- 7.4 Delineate Drainage Area DIT-2
- 7.5 Ditch Node Design DIT-3
- 7.6 Delineate Drainage Area DIT-3
- 7.7 Ditch Node Design DIT-4
- 7.8 Delineate Drainage Area DIT-4
- 7.9 Ditch Link DIT-1
- 7.10 Ditch Link DIT-2
- 7.11 Ditch Link DIT-3

## **8 Ditch Networks**

- 8.1 Ditch Network Design
- 8.2 Ditch Link Review
- 8.3 Select Active Network

- 9 Profiles**
  - 9.1 Storm Drainage Profile Design
  - 9.2 Projecting Profiles to a Chain
  - 9.3 Ditch Profile
  - 9.4 Editing Links via Profiles
- 10 Drainage Navigator**
  - 10.1 Navigating/Query
  - 10.2 Navigating/Global Editor
  - 10.3 Re-Run the Network
- 11 System Modification**
  - 11.1 Storm Drainage Network Modification
  - 11.2 Ditch Network Modification
  - 11.3 Ditch Link Modification
  - 11.4 Redesign Ditch Network & Review
- 12 Reports**
  - 12.1 Customized Reports
  - 12.2 Excel Tab Builder
  - 12.3 Standard Reports
- 13 Storm Drainage Labeling**
  - 13.1 Plan View Labeling
  - 13.2 Profile View Labeling
- 14 Design & Computation Manager with Drainage Links**
  - 14.1 Set Link Symbolology
  - 14.2 Label Short Pipe Links
  - 14.3 Compute Link Quantities
  - 14.4 Alternate Pay Items for Links

<b>Appendix A</b>	<b>T.D.O.T. Geopak Drainage Nodes</b>
<b>Appendix B</b>	<b>Completing Drainage Areas</b>
<b>Appendix C</b>	<b>Common Network Errors and Fixes</b>
<b>Appendix D</b>	<b>Manning's N and Intercept K Values</b>
<b>Appendix E</b>	<b>Manning's N for Uniform Flow</b>
<b>Appendix F</b>	<b>Total Energy in Open Channel Flow</b>
<b>Appendix G</b>	<b>Pipe Selection Criteria</b>
<b>Appendix H</b>	<b>Storm Sewer Sketch</b>
<b>Appendix I</b>	<b>IDF Zone Location Map</b>
<b>Appendix J</b>	<b>Hydrologic Design Criteria</b>
<b>Appendix K</b>	<b>Catch Basin Data Table</b>